



**SECURE
HOME
PROTECT.COM**

User Manual

Fingerprint Padlock – Model HSP-FM570

Specifications:

- **Model:** HSP-FM570
- **Unlock method:** Fingerprint
- **Number of storable fingerprints:** 10
- **Charging type:** Micro-USB
- **Emergency unlock:** Morse code
- **Standby time:** Approximately 6 months
- **Material:** Zinc alloy
- **Dimensions:** 76 x 46 x 13 mm
- **IP Rating:** IP56
- **Operating temperature:** -10°C to 50°C



Fingerprint Registration Instructions:

Before registering, **any fingerprint can unlock the lock.**

1. Unlock the lock with the fingerprint you wish to register. **Do not remove your finger** until the **blue light turns on.**
2. Press the same finger on the sensor **at different angles** about 10 times. The **green light** will turn on if successful.
⚠ If you press the **same exact spot twice**, the **red light** will turn on.
3. When the green light turns on, you can register a **second fingerprint** by repeating the same steps. If successful, the green light will turn off.

Add Additional Fingerprints:

1. Unlock the lock and **keep your finger on the sensor** until the **blue light** turns on.
2. Press a **new finger** multiple times until the **blue light turns off**, then release your finger.
⚠ If you take too long, the process will fail. Repeat the steps.

Setting the Emergency Morse Code:

1. After registering a fingerprint, unlock the lock and keep your finger on the sensor until the **white light** turns on. Release your finger. The **green light** will appear.
2. While the green light is on, enter the **first digit** of your Morse code by **pressing your finger the number of times desired** (e.g., 5 presses = digit 5), then wait for the **blue light.**
3. When the blue light is on, enter the **second digit** in the same way, then wait for the light to turn off.
4. **Remember both digits** — they are your **emergency Morse code.**



SECURE HOME PROTECT.COM

Emergency Unlock via Morse Code:

1. If no fingerprint works, press any finger on the sensor until the **white light flashes**, then release. The **green light** will appear.
2. While the green light is on, enter the **first digit** of your Morse code, wait for the **blue light**, then enter the **second digit**.

⚠ If the code is incorrect, the **red light** will flash. Repeat until successful.

3. Once unlocked using Morse code, the lock will **reset to factory settings**.

✅ **Default Morse code** (if not configured): **3 and 3**

→ Press 3 times during green light, then 3 times during blue light.

Reset to Factory Settings:

1. After unlocking, keep your finger on the sensor until the **red light** turns on.
2. Release your finger. **All fingerprints and Morse code will be erased.**